(DETAIL A)

C161 — DRIVER SIDE REAR FRAME RAIL

E - SERIES FORD: P/W F52 20A BCM; B/W F28 20A BCM; E/N F46 20A BCM; P/O F48 20A BCM; P/W F36 20A BCM

F550: N F36 15A BCM; E / N F15 15A BCM; Y F14 15A BCM; G F13 15A BCM; B F15 15A BCM

CHEVY: N F3 15A BCM; G F26 15A BCM; Y F21 15A BCM; G F3 15A BCM; B F66 15A BCM

(DETAIL B)

E - SERIES FORD: 20 P — Y / O F13 40A BCM — UNDER DRIVER DASH

F550 FORD: 20 P — W / B F10 15A BCM — DOOR SIDE DRIVER DASH

CHEVY: 20 P — N F33 30A BCM — PILLAR BEHIND DRIVER

(DETAIL C)

E - SERIES FORD: BEHIND OEM RADIO — C137: R — B H1 15A BCM; Y — W / R F29 20A BCM; K — K / E

F550 FORD: BEHIND OEM RADIO — C137: R — E / B F36 30A BCM; Y — E / R F29 30A BCM; K — K / B

CHEVY: BEHIND OEM RADIO — C137: R — B / K F11 15A BCM; Y — R / W F26 15A BCM; K — K

(DETAIL D)

E - SERIES FORD: DRIVER STEPWELL — 17 P — E / P F7 15A BCM; 17 G — K

F550 FORD: UNDER PASSENGER DASH — 17 P — E / P F13 15A BCM; 17 G — K

CHEVY: PASSENGER STEPWELL — 17 P — D-B/WH F36 15A BCM; 17 G — K

(DETAIL E)

E - SERIES FORD: ENGINE COMP — DRV P/W 03 B; 02 K/W; P/W DRV

CHEVY: ENGINE COMP — DRV DG 03 B; 02 K/W; DG DRV

(DETAIL F)

E - SERIES FORD: UNDER DRIVER DASH — 08 O — Y / E — E / P — DR ENGINE COMPARTMENT

F550 FORD: 08 O — B / E — DOOR SIDE DRIVER DASH

CHEVY: DOOR SIDE DRIVER DASH — 12 R — 08 O — O / K — ECM X1-34 — G — UNDER DRIVER DASH

(DETAIL G)

INSIDE DRIVER SIDE REAR CORNER — C161 N, W, Y, G, R — FRONT CAP — LEFT TURN, LEFT STOP/TURN, RIGHT TURN, RIGHT STOP/TURN, STOP — COMBINER — GROUND — W — C161 N, W, Y, G — REAR CAP

COMBINER WHEN AMBER TURNS ARE NOT USED

COLOR CODES	
B	BLUE
E	GREY
G	GREEN
K	BLACK
I	PINK
N	BROWN
O	ORANGE
P	PURPLE
R	RED
T	TAN
Y	YELLOW
W	WHITE

LEGEND
CONNECTION
NO CONNECTION
DIODE
FUSE
SPEAKER
SWITCH
DUAL SWITCH
RHEOSTAT
LED
JUMPER
GROUND
CONNECTOR
2 WIRE LIGHT
3 WIRE LIGHT

AUX AC CONTROL PANEL — RDS, K2, RDM, RDL — CL, CON, BF5 40A BCM, BF4 60A BCM

EP4 & AC CONTROL PANEL — HA, RDL, K1, CL, CON, MED, HI, BF5 40A BCM, BF4 60A BCM, BF3 40A BCM

11 G; GROUND: 08 G, 06 G, 01 G, 09 G

IGNITION: 15A F10 BCM 08 R; 15A F09 BCM 07 I; 15A F08 BCM 06 R; 15A F07 BCM; 15A F06 BCM; 15A F05 BCM; 15A F04 BCM; 15A F03 BCM; 15A F02 BCM; 15A F01 BCM

BATTERY: M; RDM; RDL; 15A BF1 BCM; 25A BF2 BCM 10 R; 15A BF3 BCM; 15A BF4 BCM; 20 P

SEE DETAIL B — 20 P

KCOMM PREWIRE — 09 N, 18 W, 18 Y, 18 R, 09 B

C109 — 23 Y, 08 G — LH WINDOW AJAR

C196 — 23 Y, 08 G — RH WINDOW AJAR

C199 — 23 Y, 08 G — REAR WINDOW AJAR

LH BRAKE C149; LH BRAKE TAIL C140; CENTER BRAKE C145; RH BRAKE C143; RH BRAKE TAIL C146 — 09 B, 05 G

C148 LH TURN — 18 Y, 05 G

C147 LH MIDTURN MARKER — 09 N, 18 Y, 05 G

C142 RH TURN — 18 R, 05 G

C141 RH MIDTURN MARKER — 09 N, 18 R, 05 G

C144 RH BACKUP — 18 W, 05 G

C150 LH BACKUP — 18 W, 05 G

C161 — SEE DETAIL A — 09 N, 18 W, 18 Y, 18 R, 09 B

C161 — SEE DETAIL G — 09 N, 18 W, 18 Y, 18 R, 09 B, 05 G

C118E RH DOME LIGHT — 08 K, 11 G

C118A LH DOME LIGHT — 08 K, 11 G

C118C RH DOME LIGHT — 08 K, 11 G

C118B LH DOME LIGHT — 08 K, 11 G

C118F RH DOME LIGHT — 08 K, 11 G

C118D LH DOME LIGHT — 08 K, 11 G

L909 RH EXIT LIGHT — 07 I, 08 G

L910 RH EXIT LIGHT — 07 I, 08 G

L912 LH EXIT LIGHT — 07 I, 08 G

L913 LH EXIT LIGHT — 07 I, 08 G

L911 REAR EXIT LIGHT — 07 I, 08 G

C190A RH SIDE UPPER MARKER — 09 N, 05 G

C190B RH REAR MARKER — 09 N, 05 G

C190C RH REAR CENTER MARKER — 09 N, 05 G

C190D REAR CENTER MARKER — 09 N, 05 G

C190E LH REAR CENTER MARKER — 09 N, 05 G

C190F LH REAR MARKER — 09 N, 05 G

C190G LH SIDE UPPER MARKER — 09 N, 05 G

DRIVER REAR FRAME RAIL — 05 G

TAG LIGHT — C153 — 09 N, 05 G

WIN AJ LIGHT — 23 Y — AMBER — 06 R

08 O — SEE DETAIL F

DOME LIGHTS — 09 N, 08 R, 08 K — ON/OFF

ENTRY DOOR — 09 N, 09 W, 08 O, 09 Y, 06 G — ON/OFF/ON

DRIVER MAP LIGHT — DML — 17 P, 17 G — SEE DETAIL D

200A ALTERNATOR; 140A ALTERNATOR — STARTER — TRANSMISSION

BATTERY; BATTERY; BATTERY — MAIN FUSE 150A; MAIN FUSE 100A; MAIN FUSE 60A

LIFT — MAIN FUSE 60A; DIODE

RH FRONT MARKER — C190A — 09 N, 09 G

RH FRONT CENTER MARKER — C190B — 09 N, 09 G

FRONT CENTER MARKER — C190C — 09 N, 09 G

LH FRONT CENTER MARKER — C190D — 09 N, 09 G

LH FRONT MARKER — C190E — 09 N, 09 G

FAIRBOX — L916 — 09 N, 09 G

STEP LIGHT SWITCH — L915 — 08 R, 09 O, 08 K

EXTERIOR ENTRY DOOR KEY SWITCH — C116 — 09 W, 01 G, 09 Y, 10 R

C113 DOOR ENTRY MODULE — 01 G, 09 W, 09 Y, 10 R

ABOVE DOOR LIGHT — 11 G, 08 K

INT STEP LIGHT — 09 O, 11 G

INT STEP LIGHT — 09 O, 11 G

EXT STEP LIGHT — 09 O, 11 G

REV	ECN	DESCRIPTION	DATE	BY

REVISION NO: EP4 OVERALL LAYOUT

MATERIAL: SEE BOM

THIS DRAWING AND ALL INFORMATION THEREIN IS THE PROPERTY OF REV GROUP INC.

TOLERANCES UNLESS NOTED .XX +/- .06, .XXX +/- .005, ANG +/- 1°

ALL DIMENSIONS IN INCHES UNLESS NOTED

FORM F-2-2LEI REVISION A (09/14/2015)

DRAWN BY: Virgil Adams

DATE: 12/22/2016

SCALE: NTS

SHEET NO: 1 OF 1

SHEET SIZE: E

WEIGHT:

RCN: xxx

TITLE: xxxx

DRAWING NO: EP4 OVERALL LAYOUT