(DETAIL A)

C161 — DRIVER SIDE REAR FRAME RAIL

E - SERIES FORD: P/W F52 20A BCUI; B/W F28 20A BCUI; E/N F46 20A BCUI; P/O F48 20A BCUI; P/W F30 20A BCUI

F550: N F36 15A BCUI; E / N F15 15A BCUI; Y F14 15A BCUI; G F13 15A BCUI; B F15 15A BCUI

CHEVY: N F3 15A BCUI; G F26 15A BCUI; Y F21 15A BCUI; G F3 15A BCUI; B F66 15A BCUI

(DETAIL B)

E - SERIES FORD: 20 P — Y / O F13 40A BCUI — UNDER DRIVER DASH

F550 FORD: 20 P — W / B F10 15A BCUI — DOOR SIDE DRIVER DASH

CHEVY: 20 P — N F33 15A BCUI — PILLAR BEHIND DRIVER

(DETAIL C)

BEHIND OEM RADIO — C137

E - SERIES FORD: R — B F41 15A BCUI; Y — W / R F29 20A BCUI; K — K / E

F550 FORD: R — E / B F36 20A BCUI; Y — E / R F29 20A BCUI; K — K / B

CHEVY: R — B / K F11 15A BCUI; Y — R / W F26 15A BCUI; K — K

(DETAIL D)

DRIVER STEPWELL

E - SERIES FORD: 17 P — E / P F7 15A BCUI; 17 G — K

UNDER PASSENGER DASH

F550 FORD: 17 P — E / P F21 15A BCUI; 17 G — K

PASSENGER STEPWELL

CHEVY: 17 P — D-B/WH F36 15A BCUI; 17 G — K

(DETAIL E)

ENGINE COMP

E - SERIES FORD: OEM P/W — 02 K/W; 03 B — P/W OEM

ENGINE COMP

CHEVY: OEM DG — 02 K/W; 03 B — DG OEM

(DETAIL F)

UNDER DRIVER DASH — DR ENGINE COMPARTMENT

E - SERIES FORD: 08 O — Y / E — E / P

F550 FORD: 08 O — B / E

DOOR SIDE DRIVER DASH — UNDER DRIVER DASH

CHEVY: 08 O — G; 12 R — O / K — ECM X1-34

(DETAIL G)

INSIDE DRIVER SIDE REAR CORNER — C161 — FRONT CAP — REAR CAP

N; W; Y — LEFT TURN; LEFT STOP/TURN; G — RIGHT TURN; RIGHT STOP/TURN; R — STOP; COMBINER; GROUND; W

COMBINER WHEN AMBER TURNS ARE NOT USED

| COLOR CODES | |
|---|---|
| B | BLUE |
| E | GREY |
| G | GREEN |
| K | BLACK |
| I | PINK |
| N | BROWN |
| O | ORANGE |
| P | PURPLE |
| R | RED |
| T | TAN |
| Y | YELLOW |
| W | WHITE |

| LEGEND |
|---|
| CONNECTION |
| NO CONNECTION |
| DIODE |
| FUSE |
| SPEAKER |
| SWITCH |
| DUAL SWITCH |
| RHEOSTAT |
| LED |
| JUMPER |
| GROUND |
| CONNECTOR |
| 2 WIRE LIGHT |
| 3 WIRE LIGHT |

AUX AC CONTROL PANEL — RDS; K2; RDM; RDL; CL; CON; BF5 40A BCUI 10A; BF4 40A BCUI 40A

EP4 & AC CONTROL PANEL — HA; RDL; K1; CL; CON; MED; HI; BF5 40A BCUI; BF4 40A BCUI; BF3 40A BCUI; BF2 40A BCUI

GROUND: 11 G; 07 G; 06 G; 01 G; 09 G

IGNITION: 15A F10 BCTB — 08 R; F09 — 06 R; F08 — 07 R; F07; F06; F05; F04; F03; F02; F01

BATTERY: M; RDM; RDL; 15A BF1 BCTB; 25A BF2 BCTB — 10 R; 15A BF3 BCTB; 15A BF4 BCTB; 20 P

SEE DETAIL B — 20 P

KCOMM PREWIRE — 09 N; 18 W; 18 Y; 18 R; 09 B

LH BRAKE — C149 — 09 B; 05 G

LH BRAKE TAIL — C140 — 09 N; 09 B; 05 G

CENTER BRAKE — C145 — 09 B; 05 G

RH BRAKE — C143 — 09 B; 05 G

RH BRAKE TAIL — C146 — 09 N; 09 B; 05 G

C161 — SEE DETAIL A — 09 N; 18 W; 18 Y; 18 R; 09 B

C161 — 09 N; 18 W; 18 Y; 18 R; 09 B

C161 — SEE DETAIL G — 09 N; 18 W; 18 Y; 18 R; 09 B; 05 G

C148 — 18 Y; 05 G — LH TURN

C147 — 09 N; 18 Y; 05 G — LH MIDTURN MARKER

C142 — 18 R; 05 G — RH TURN

C141 — 09 N; 18 R; 05 G — RH MIDTURN MARKER

C144 — 18 W; 05 G — RH BACKUP

C150 — 18 W; 05 G — LH BACKUP

C190A — 09 N; 05 G — RH SIDE UPPER MARKER

C190B — 09 N; 05 G — RH REAR MARKER

C190C — 09 N; 05 G — RH REAR CENTER MARKER

C190D — 09 N; 05 G — REAR CENTER MARKER

C190E — 09 N; 05 G — LH REAR CENTER MARKER

C190F — 09 N; 05 G — LH REAR MARKER

C190G — 09 N; 05 G — LH SIDE UPPER MARKER

05 G — DRIVER REAR FRAME RAIL

TAG LIGHT — C153 — 09 N; 05 G

C118E — 08 K; 11 G — RH DOME LIGHT

C118C — 08 K; 11 G — RH DOME LIGHT

C118F — 08 K; 11 G — RH DOME LIGHT

C118A — 08 K; 11 G — LH DOME LIGHT

C118B — 08 K; 11 G — LH DOME LIGHT

C118D — 08 K; 11 G — LH DOME LIGHT

C108A — 07 P; 07 O; 07 G — HEATER 2

08 O — SEE DETAIL F

09 N; 07 R; 07 O — 06 G — REAR HEATER 2

09 N; 08 K; 08 K — 06 G — DOME LIGHTS

09 N; 09 W; 08 O; 09 Y — 06 G — ENTRY DOOR

DRIVER MAP LIGHT — DML — 17 P; 17 G — SEE DETAIL D

200A ALTERNATOR; 140A ALTERNATOR — STARTER

RH FRONT MARKER — C190A — 09 N; 09 G

RH FRONT CENTER MARKER — C190B — 09 N; 09 G

FRONT CENTER MARKER — C190C — 09 N; 09 G

LH FRONT CENTER MARKER — C190D — 09 N; 09 G

LH FRONT MARKER — C190E — 09 N; 09 G

FAIRBOX — L916 — 09 N; 09 G

BATTERY; BATTERY; BATTERY — TRANSMISSION

LIFT

STEP LIGHT SWITCH — L915 — 08 R; 09 O; 08 K

EXTERIOR ENTRY DOOR KEY SWITCH — C116 — 09 W; 01 G; 09 Y; 10 R

C113 — 01 G; 09 W; 09 Y; 10 R — DOOR ENTRY MODULE

ABOVE DOOR LIGHT — 11 G; 08 K

INT STEP LIGHT — 09 O; 11 G

INT STEP LIGHT — 09 O; 11 G

EXT STEP LIGHT — 09 O; 11 G

| REV | ECN | DESCRIPTION | DATE | BY |
|---|---|---|---|---|
| | | | | |

REVISION NO: EP4 OVERALL LAYOUT

MATERIAL: **SEE BOM**

THIS DRAWING AND ALL INFORMATION THEREIN IS THE PROPERTY OF REV GROUP INC.

TOLERANCES UNLESS NOTED .XX +/- .06; .XXX +/- .005; ANG +/- 1°

ALL DIMENSIONS IN INCHES UNLESS NOTED

FORM F-2-2LEI REVISION A (09/14/2010)

DRAWN BY: **Virgil Adams** | DATE: **12/22/2016** | SCALE: **NTS**

SHEET NO: **1 OF 1** | SHEET SIZE: **E** | WEIGHT:

RCN: **xxx** | TITLE: **xxxx** | DRAWING NO: **EP4 OVERALL LAYOUT**